



For any help or enquiries please contact;

Gel-clear Ltd  
145 Bolton Rd  
Darwen  
Lancs  
BB3 1DF

[info@gel-clear.co.uk](mailto:info@gel-clear.co.uk)

[www.gel-clear.co.uk](http://www.gel-clear.co.uk)

**0844 330 3643**



*Gel-clear and the Gel-clear logo are registered trade marks  
Gel-clears proprietary formula is owned by Gel-clear Ltd*



Condensate drain treatment tablets

**Product Information Guide**

Instructions for use



## Description

Gel-clear is the simple, low cost, effective solution to blocked condensate drains. Gel-clears patented, proprietary formula, is a purpose developed condensate drain tablet for the food retail display case, and the treatment of slime and jelly in refrigeration drainage.

Effective for 12 months, Gel-clear condensate drain tablets are a unique approach to blocked condensate case drains preventing the build up of jelly and slime.

Gel-clear is safe and simple to use, one tablet - triple action, cleans - coats - protects.

Gel-clear is safe to use with condensate pumps and Vacuum drainage systems.

## Key properties

Gel-clear tablets are specially formulated to slow release into the condensate waste water with patented coating agents to leave a protective film on the case plumbing remaining effective for long periods.

The tablet is 100% soluble, leaving no waxy residues, and approved for use with all types of condensate pumps.

Gel-clears patented formula is NSF listed for use in food display chillers.

One tablet per case, per year. Can be installed as part of PPM, or reactive maintenance.

Suitable for all case types. Easy to install, locks in place never moves.

Can be left in case during cleaning. Approved for discharge into UK sewer systems.

## Recommended use

It is recommended that tablets are installed during a deep clean for ease of installation, but not essential, Gel-clear is as effective whenever it is used.

Gel-clear is approved for use with all condensate pumps, but upon installation, pour water over the tablet until the pump enters cycle. This is to coat the discharge line.

Once the tablet has disappeared, the coating remains effective for long periods preventing slime and jelly for over a year.

Use a sticker to identify that the case has been treated, fill in the date, replace annually or during each deep clean.



## Instructions for use

Using Gel-clear condensate drain tablets could not be simpler! you simply place the tablet in the condensate pan.....that's it!

Prior to your condensate drain treatment, we ask you follow some simple guidelines to enable you to achieve the best results. Check the case plumbing and drains, that they are not blocked.

Before starting any work on refrigeration condensate drain pan, we recommend the correct PPE be worn and operatives are fully aware of the risks of contact with dirty condensate drain water.

Place tablet in condensate drain pan ensuring it is in contact with the water.

Place the tablet near the coil, away from the drain outlet, one tablet per case.

## Hazards

Do not eat or drink when using Gel-clear  
Wear gloves and eye protection when handling  
IF ON SKIN - Wash with plenty of water, if irritation occurs, seek medical advice  
IF IN EYES - Rinse with water for several minutes, if irritation occurs, seek medical advice. Dispose of unused contents in accordance with national regulations, see SDS